

Last Update :13-Jan-2019 (10:15)



Printed Time : 22-Mar-2022 (10:12)



Ink - Brother (Original)

รายละเอียด

1 ประกัน

BROTHER LC-3617 BK	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	390	-
BROTHER LC-3617 C	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	390	-
BROTHER LC-3617 M	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	390	-
BROTHER LC-3617 Y	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	390	-
BROTHER LC-3619XL BK	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	670	-
BROTHER LC-3619XL C	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	570	-
BROTHER LC-3619XL M	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	570	-
BROTHER LC-3619XL Y	For Brother : MFC-J2330DW / MFC-2730DW / MFC-J3530DW / MFC-3930DW 	570	-
BROTHER LC-38 BK	For Brother : DCP-145C / DCP-165C / DCP-195C-375CW / MFC-250C / MFC-255CW / MFC-257CW-290C / MFC-295CN 	450	-
BROTHER LC-38 C	For Brother : DCP-145C / DCP-165C / DCP-195C-375CW / MFC-250C / MFC-255CW / MFC-257CW-290C / MFC-295CN 	310	-
BROTHER LC-38 M	For Brother : DCP-145C / DCP-165C / DCP-195C-375CW / MFC-250C / MFC-255CW / MFC-257CW-290C / MFC-295CN 	310	-
BROTHER LC-38 Y	For Brother : DCP-145C / DCP-165C / DCP-195C-375CW / MFC-250C / MFC-255CW / MFC-257CW-290C / MFC-295CN 	310	-
BROTHER LC-39 BK	For Brother : DCP-J125 / DCP-J315W / DCP-J515W / MFC-J220 / MFC-J265W / MFC-J410 / MFC-J415W 	520	-
BROTHER LC-39 C	For Brother : DCP-J125 / DCP-J315W / DCP-J515W / MFC-J220 / MFC-J265W / MFC-J410 / MFC-J415W 	315	-
BROTHER LC-39 M	For Brother : DCP-J125 / DCP-J315W / DCP-J515W / MFC-J220 / MFC-J265W / MFC-J410 / MFC-J415W 	315	-
BROTHER LC-39 Y	For Brother : DCP-J125 / DCP-J315W / DCP-J515W / MFC-J220 / MFC-J265W / MFC-J410 / MFC-J415W 	315	-
BROTHER LC-535XL C	For Brother : DCP-J100 / DCP-J105 / MFC-J200 	320	-

BROTHER LC-535XL M	For Brother : DCP-J100 / DCP-J105 / MFC-J200 	320	-
BROTHER LC-535XL Y	For Brother : DCP-J100 / DCP-J105 / MFC-J200 	320	-
BROTHER LC-539XL BK	For Brother : DCP-J100 / DCP-J105 / MFC-J200 	340	-
BROTHER LC-563 BK	For Brother : MFC-J2310 / MFC-J2510 / MFC-J3520 / MFC-J3720 	400	-
BROTHER LC-563 C	For Brother : MFC-J2310 / MFC-J2510 / MFC-J3520 / MFC-J3720 	400	-
BROTHER LC-563 M	For Brother : MFC-J2310 / MFC-J2510 / MFC-J3520 / MFC-J3720 	400	-
BROTHER LC-563 Y	For Brother : MFC-J2310 / MFC-J2510 / MFC-J3520 / MFC-J3720 	400	-
BROTHER LC-565XL C	For Brother : MFC-J2310 / MFC-J2510 	500	-
BROTHER LC-565XL M	For Brother : MFC-J2310 / MFC-J2510 	500	-
BROTHER LC-565XL Y	For Brother : MFC-J2310 / MFC-J2510 	500	-
BROTHER LC-569XL BK	For Brother : MFC-J3520 / MFC-J3720 	590	-
BROTHER LC-663 BK	For Brother : MFC-J2320 / MFC-J2720 	415	-
BROTHER LC-663 C	For Brother : MFC-J2320 / MFC-J2720 	415	-
BROTHER LC-663 M	For Brother : MFC-J2320 / MFC-J2720 	415	-
BROTHER LC-663 Y	For Brother : MFC-J2320 / MFC-J2720 	415	-
BROTHER LC-665XL C	For Brother : MFC-J2320 / MFC-J2720 	500	-
BROTHER LC-665XL M	For Brother : MFC-J2320 / MFC-J2720 	500	-
BROTHER LC-665XL Y	For Brother : MFC-J2320 / MFC-J2720 	500	-
BROTHER LC-669XL BK	For Brother : MFC-J2320 / MFC-J2720 	590	-
BROTHER LC-73 BK	For Brother : DCP-J525W / DCP-J725W / DCP-J925DW / MFC-J430W / MFC-J432W / MFC-J325DW / MFC-J825DW / MFC-5910DW / MFC-635 J6510DW / MFC-J670DW / MFC-J6910DW 		-
BROTHER LC-73 C	For Brother : DCP-J525W / DCP-J725W / DCP-J925DW / MFC-J430W / MFC-J432W / MFC-J325DW / MFC-J825DW / MFC-5910DW / MFC-440 J6510DW / MFC-J670DW / MFC-J6910DW 		-
BROTHER LC-73 M	For Brother : DCP-J525W / DCP-J725W / DCP-J925DW / MFC-J430W / MFC-J432W / MFC-J325DW / MFC-J825DW / MFC-5910DW / MFC-440 J6510DW / MFC-J670DW / MFC-J6910DW 		-
BROTHER LC-73 Y	For Brother : DCP-J525W / DCP-J725W / DCP-J925DW / MFC-J430W / MFC-J432W / MFC-J325DW / MFC-J825DW / MFC-5910DW / MFC-440 J6510DW / MFC-J670DW / MFC-J6910DW 		-



CANON CL-57 COL	For Canon : Pixma E400 / E410 / E480 	555	-
CANON CL-741 COL	For Canon : Pixma MG2170 / MG2270 / MG3170 / MG3570 / MG4170 / MG4270 / MX377 / MX397 / MX437 / MX457 / MX517 / MX527 / GM2070 	810	-
CANON CL-746 COL	For Canon : Pixma MG2470 / MG2570 	780	-
CANON CL-811 COL	For Canon : Pixma IP2770 / IP2772 / MP237 / MP245 / MP258 / MP268 / MP276 / MP287 / MP486 / MP496 / MP497 / MX328 / MX338 / MX347 / MX366 / MX416 / MX426 	985	-
CANON CL-98 COL	For Canon : Pixma E500 	565	-
CANON CLI-726 C	For Canon : Pixma IP4870 / MG5170 / MG5270 / MG6170 / MG8170 	530	-
CANON CLI-726 M	For Canon : Pixma IP4870 / MG5170 / MG5270 / MG6170 / MG8170 	530	-
CANON CLI-726 Y	For Canon : Pixma IP4870 / MG5170 / MG5270 / MG6170 / MG8170 	530	-
CANON CLI-751 BK	For Canon : Pixma IP7270 / MG5470 / MG6470 / MX727 / MX927 	560	-
CANON CLI-751 C	For Canon : Pixma IP7270 / MG5470 / MG6470 / MX727 / MX927 	560	-
CANON CLI-751 M	For Canon : Pixma IP7270 / IP8770 / IX6770 / IX6870 / MG5470 / MG5570 / MG6370 / MG6470 / MG7170 / MX727 / MX927 / MX7570 	560	-
CANON CLI-751 Y	For Canon : Pixma IP7270 / MG5470 / MG6470 / MX727 / MX927 	560	-
CANON CLI-771 BK	For Canon : Pixma MG5770 / MG6870 / MG7770 	570	-
CANON CLI-771 M	For Canon : Pixma MG5770 / MG6870 / MG7770 	570	-
CANON CLI-771 Y	For Canon : Pixma MG5770 / MG6870 / MG7770 	570	-
CANON PG-47 BK	For Canon : Pixma E400 / E410 / E480 	320	-
CANON PG-740 BK	For Canon : Pixma MG2170 / MG2270 / MG3170 / MG3570 / MG4170 / MG4270 / MX377 / MX397 / MX437 / MX457 / MX517 / MX527 	565	-
CANON PG-745 BK	For Canon : Pixma IP2870 / MG2470 / MG2570 	570	-
CANON PG-810 BK	For Canon : Pixma IP2770 / IP2772 / MP237 / MP245 / MP258 / MP268 / MP276 / MP287 / MP486 / MP496 / MP467 / MX328 / MX338 / MX347 / MX357 / MX416 / MX426 	740	-
CANON PG-88 BK	For Canon : Pixma E500 	460	-
CANON PG-89 BK	For Canon : Pixma E560 	455	-

CANON PGI-35 BK	For Canon : Pixma iP100 	510	-
CANON PGI-725 BK	For Canon : Pixma iP4870 / iP4970 / IX6560 / MX897 / MX886 / MG5170 / MG5270 / MG5370 / MG6170 / MG6270 / MG8170 / MG8270 	535	-
CANON PGI-750 PGBK	For Canon : Pixma IP7270 / IP8770 / IX6770 / IX6870 / MG5470 / MG5570 / MG6370 / MG6470 / MG7170 / MX727 / MX927 / MX7570 	690	-
 Ink - EPSON (Original)	รายละเอียด	1	ประกัน
EPSON T0491 BK	For Epson : R210 / R230 / R310 / R350 / RX510 / RX630 / RX650 	545	-
EPSON T0493 M	For Epson : R210 / R230 / R310 / R350 / RX510 / RX630 / RX650 	550	-
EPSON T188 BK	For Epson : WF-7111 / WF-7611 	1,420	-
EPSON T188 C	For Epson : WF-7111 / WF-7611 	930	-
EPSON T188 M	For Epson : WF-7111 / WF-7611 	930	-
EPSON T188 Y	For Epson : WF-7111 / WF-7611 	930	-
 Ink - HP (Original)	รายละเอียด	1	ประกัน
HP 46 BK	For HP : 2020HC / 2520HC / 2029 / 2529 / 4729 	415	-
HP 46 COL	For HP : 2020HC / 2520HC / 2029 / 2529 / 4729 	400	-
HP 60 BK	For HP : C4795 / C4780 / D110A / D1660 / D2530 / D2545 / D2560 / D2660 / D2680 / F4280 	770	-
HP 60 COL	For HP : C4795 / C4780 / D110A / D1660 / D2530 / D2545 / D2560 / D2660 / D2680 / F4280 	720	-
HP 61 COL	For HP : Deskjet : 1000 / 1050 / 1510 / 1511 / 1514 / 2000 / 2050 / 2510 / 2511 / 2540 / 3000 / 3050 / 3060 / Officejet : 2620 / 4630 / ENVY : 4500 / 5530 	920	-
HP 63 BK	For HP : 1110 / 1112 / 1115 / 2130 / 2131 / 2132 / 3630 / 3632 / 3830 / 4650 / ENVY 4520 	690	-
HP 63 COL	For HP : 1110 / 1112 / 1115 / 2130 / 2131 / 2132 / 3630 / 3632 / 3830 / 4650 / ENVY 4520 	895	-
HP 65 BK	For HP : DeskJet 2220 / 2255 / 2621 / 2622 / 2623 / 2655 / 3720 / 3755 / 3758 / ENVY 5055 / AMP 100 	550	-
HP 65 COL	For HP : DeskJet 2220 / 2255 / 2621 / 2622 / 2623 / 2655 / 3720 / 3755 / 3758 / ENVY 5055 / AMP 100 	475	-
HP 67 BK	For HP : ENVY 6000 series / ENVY Pro 6400 series / Deskjet 1200 / Deskjet 2300 / Deskjet 2700 / Deskjet Plus 4100 	495	-

HP 67 COL	For HP : ENVY 6000 series / ENVY Pro 6400 series / Deskjet 1200 / Deskjet 2300 / Deskjet 2700 / Deskjet Plus 4100 	495	-
HP 678 BK	For HP : Deskjet Ink Advantage 1015 / 1515 / 1518 / 2515 / 2545 / 2645 / 2648 / 3515 / 3545 / 3548 / 4515 / 4518 / 4645 	375	-
HP 678 COL	For HP : Deskjet Ink Advantage 1015 / 1515 / 1518 / 2515 / 2545 / 2645 / 2648 / 3515 / 3545 / 3548 / 4515 / 4518 / 4645 	375	-
HP 680 BK	For HP : 1110 / 1115 / 2130 / 2135 / 3630 / 3635 / 3830 / 3835 / 4520 / 4535 / 4650 / 5075 	355	-
HP 680 COL	For HP : 1110 / 1115 / 2130 / 2135 / 3630 / 3635 / 3830 / 3835 / 4520 / 4535 / 4650 / 5075 	355	-
HP 682 BK	For HP : DeskJet Advantage 1200 / 2300 / 2700 / 4100 / 6000 series / 6400 series 	365	-
HP 682 COL	For HP : DeskJet Advantage 1200 / 2300 / 2700 / 4100 / 6000 series / 6400 series 	365	-
HP 703 BK	For HP : Deskjet D730 / F735 / K109A / K109A / K209A / K209G / PHOTOSMART K510A 	390	-
HP 703 COL	For HP : Deskjet D730 / F735 / K109A / K109A / K209A / K209G / PHOTOSMART K510A 	390	-
HP 704 BK	For HP : Deskjet Ink Advantage 2010 / 2060 	405	-
HP 704 COL	For HP : Deskjet Ink Advantage 2010 / 2060 	405	-
HP 711 BK	For HP : Designjet T120 / T520 	1,180	-
HP 711 C	For HP : Designjet T120 / T520 	1,020	-
HP 711 M	For HP : Designjet T120 / T520 	1,020	-
HP 711 Y	For HP : Designjet T120 / T520 	1,020	-
HP 920XL BK	For HP : 6000 / 6500 / 6500A / 6500APlus / 7000 / 7500A 	1,380	-
HP 932XL BK	For HP : 6100 / 6600 / 6700 / 7110 / 7610 	1,330	-
HP 933XL C	For HP : 6100 / 6600 / 6700 Premium / 7110 / 7610 	700	-
HP 933XL M	For HP : 6100 / 6600 / 6700 Premium / 7110 / 7610 	700	-
HP 933XL Y	For HP : 6100 / 6600 / 6700 Premium / 7110 / 7610 	700	-
HP 934XL BK	For HP : 6220 / 6230 / 6820 / 6830 	920	-
HP 935XL C	For HP OfficeJet Pro : 6230 / 6830 	635	-
HP 935XL M	For HP OfficeJet Pro : 6230 / 6830 	635	-
HP 935XL Y	For HP OfficeJet Pro : 6230 / 6830 	635	-

HP 95 COL	For HP : 150 / C313 / 460 / H470 / 1510 / 1600 / 1610 / 2355 / 2575 / 2610 / 2710 / 5740 / 6200 / 6210 / J6480 / 6540 / 6520 / 6620 / 6830 / 6840 / 6980 / 6988 / 7210 / 7310 / 7410 / 7850 / 8150 / 845 	1,070	-
HP 950XL BK	For HP : Officejet PRO 8100 / 8600 / 8600 Plus 	1,520	-
HP 951XL C	For HP : Officejet PRO 8100 / 8600 / 8600 Plus 	1,070	-
HP 951XL M	For HP : Officejet PRO 8100 / 8600 / 8600 Plus 	1,070	-
HP 951XL Y	For HP : Officejet PRO 8100 / 8600 / 8600 Plus 	1,070	-
HP 955XL BK	For HP : Officejet PRO 7720 / 7730 / 7740 / 8210 / 8216 / 8710 / 8720 / 8730 / 8732M / 8740 / 8745 	1,440	-
HP 955XL C	For HP : Officejet PRO 7720 / 7730 / 7740 / 8210 / 8216 / 8710 / 8720 / 8730 / 8732M / 8740 / 8745 	1,090	-
HP 955XL M	For HP : Officejet PRO 7720 / 7730 / 7740 / 8210 / 8216 / 8710 / 8720 / 8730 / 8732M / 8740 / 8745 	1,090	-
HP 955XL Y	For HP : Officejet PRO 7720 / 7730 / 7740 / 8210 / 8216 / 8710 / 8720 / 8730 / 8732M / 8740 / 8745 	1,090	-